


BBC




micro:bit

SAFETY WARNINGS

✗ DO NOT PLACE ANY METAL OBJECT ACROSS THE BBC MICRO:BIT BATTERY SOCKET.



✗ DO NOT PLACE ANY METAL OBJECTS ACROSS THE PRINTED CIRCUITS AS THIS CAN CAUSE A SHORT CIRCUIT.




✗ DO NOT USE YOUR BBC MICRO:BIT IN WATER OR WITH WET HANDS.




✗ DO NOT LEAVE YOUR BBC MICRO:BIT PLUGGED INTO ANY DEVICE UNSUPERVISED.



✗ PLEASE AVOID HANDLING THE BBC MICRO:BIT CIRCUIT BOARD WHILE PLUGGED INTO A POWER SUPPLY.



✓ PLEASE HANDLE YOUR BBC MICRO:BIT BY ITS EDGES.



✓ ALL LEADS AND ACCESSORIES USED WITH YOUR BBC MICRO:BIT SHOULD MEET THE RELEVANT STANDARDS AND BE MARKED TO SHOW THIS.




✗ CONNECTING YOUR BBC MICRO:BIT TO ANYTHING UNAPPROVED COULD DAMAGE IT.




✗ PLEASE DO NOT LEAVE YOUR BBC MICRO:BIT WITHIN REACH OF CHILDREN UNDER 8 YEARS.




✓ PLEASE OPERATE YOUR BBC MICRO:BIT IN A WELL VENTILATED ROOM.



✓ ONLY CONNECT YOUR BBC MICRO:BIT TO A POWER SUPPLY RATED AT 3VOLTS.



✓ THE MAXIMUM CURRENT SAFELY SUPPLIED TO AN EXTERNAL CIRCUIT USING THE 3V PIN ON THE EDGE CONNECTOR IS 100mA.




✗ PLEASE DO NOT STORE OR USE YOUR BBC MICRO:BIT IN EXTREMELY HOT OR COLD ENVIRONMENTS.




BATTERY WARNINGS


✓ ONLY USE ZINC-CARBON OR ALKALINE BATTERIES WITH YOUR BBC MICRO:BIT.




✓ TO REMOVE THE BATTERY PACK PINCH THE CONNECTOR WITH YOUR FINGERS.




✗ DO NOT REMOVE BY PULLING THE WIRES.




✗ PLEASE DO NOT MIX DIFFERENT TYPES OF BATTERIES OR MIX NEW AND USED BATTERIES.



✓ PLEASE USE BATTERIES OF THE SAME OR EQUIVALENT TYPE AS THOSE RECOMMENDED.



✓ PLEASE INSERT BATTERIES THE CORRECT WAY ROUND.



✓ PLEASE REMOVE SPENT BATTERIES FROM THE BATTERY HOLDER.



✗ DO NOT PLACE ANY METAL OBJECTS ACROSS THE TERMINALS AS THIS MAY SHORT-CIRCUIT THE BATTERY SUPPLY.




✗ DO NOT TRY TO CHARGE NORMAL (NON-RECHARGEABLE) BATTERIES.







micro:bit



QUICK START GUIDE

For full set up instructions, please visit:
<https://www.microbit.co.uk/getting-started>



Requirements

- A laptop or PC running Windows 7 or later, or a Mac running OS X 10.6 or later, or a smart phone or tablet.
- An 'A Male' to micro USB cable to connect your computer to your BBC micro:bit. This is the same cable that is commonly used to connect a smart phone to a computer.
- Access to the Internet.

Accessing the BBC micro:bit website

- Just go to **www.microbit.co.uk**. There are lots of tutorials and information on the website.

Coding your BBC micro:bit

- Go to **Create Code** and choose the editor that you would like to code with.
- When you have finished your script, press **run** to see it play on the on screen simulator.

Connecting your BBC micro:bit

You connect your BBC micro:bit to your computer with a micro USB cable.

- Connect the small end of the USB cable to the micro USB port on your BBC micro:bit.
- Connect the other end of the USB cable to a USB port on your computer.

Your computer should recognise your BBC micro:bit as a new drive. On computers running Windows, MICROBIT appears as a drive under Devices and drives. On a Mac it appears as a new drive under Devices.

Compiling your script

- Click **compile** in the editor. Your script is converted into a .hex file that you can transfer and run on your BBC micro:bit.
- To compile a different script click on **My Scripts**, select the script, then click **edit** and **compile**.

Transferring the file to your BBC micro:bit

- When the file has downloaded, open Finder or Windows Explorer and open the **MICROBIT** drive. Drag and drop the .hex file onto your MICROBIT drive.
- The LED on the back of your BBC micro:bit flashes during the transfer which only takes a few seconds.
- Once transferred, the code will run automatically on your BBC micro:bit. To rerun your program, press the reset button on the back of your BBC micro:bit. The reset button automatically runs the newest file on the BBC micro:bit.
- Once you transfer a file to the BBC micro:bit, you can disconnect the BBC micro:bit from your computer.

Powering your BBC micro:bit

When your BBC micro:bit is not connected to your computer with a USB, you will need 2 x AAA batteries to power it.

Using phones and tablets

- Find out how to use the BBC micro:bit App to connect your phones and tablets with the BBC micro:bit in the getting started section on the website.

